



AK-DINRAIL-SWITCH

Quick installation guide

Thank you very much for purchasing an AK-Nord product!

This short description includes an overview of the first steps in using the AK-Nord products. It shows in which way you can easily and simply integrate our products in your infrastructure and establish the first connection to our products.

If you need help when implementing the AK-Nord products or if you have any further questions regarding individual settings, we will of course be at your disposal. Please do not hesitate to call us or send us an e-mail.



+49 (0) 4821 / 804035-0



service@ak-nord.de

We will be glad to help you in particular.

In addition we recommend you to thoroughly read the corresponding manual. Please observe all recommendations, remarks and warning notes in order to guarantee a proper function.



AK-NORD
Germany
www.ak-nord.com



AK-DINRAIL-SWITCH



Page 2



AK-NORD Germany www.ak-nord.com



AK-DINRAIL-SWITCH

Connections:



Network - Connections
10/100 MBit
Auto M-DIX

LAN5

LAN4

LAN3

LAN2

LAN1





AK-DINRAIL-SWITCH

LED status display:



Power LED

LAN1 connected

3 LAN2 connected

4 LAN3 connected

5 LAN4 connected

6 LAN5 connected